



GD_PA13	JTMS
GD_PA14	JTCK
GD_PA15	JTD1
GD_PB3	JTD0
GD_PB12	SPI1_CS_TF
GD_PB14	SPI1_MISO
GD_PB13	SPI1_SCLK
GD_PB15	SPI1_MOSI
GD_PA7	TFT_SDA
GD_PA5	TFT_SCL
GD_PA8	TFT_RS
GD_PB1	TFT_RST
GD_PB2	TFT_CS
GD_PA11	GD_USB_D-
GD_PA12	GD_USB_D+
GD_PA10	GD_UART0_RX
GD_PA9	GD_UART0_TX

